

Description:

Highly concentrated essence with Vanilla and Lemon fragrance for both laundry and dry cleaning.

- Intense and long lasting fragrance
- Professional concentrated formula
- It can be used with every kind of detergent and softener
- It doesn't stain garments
- It can be used for both laundry and dry cleaning (Perc)
- Phosphate free

How To Use:

WATER: Hygienfresh Essence has to be used in the last rinse, with a limited water level.

Dosage: 1 – 3 ml of Hygienfresh Essence per Kg of dry garment, with machine fully loaded.

PERC: Hygienfresh Essence has to be used with machine fully loaded, preferably in the second bath, by dosing it in the bottom trap or with automatic dosage.

Continuous distillation: 2 – 3 ml of Hygienfresh Essence per Kg of dry garment

Manual distillation: 3 ml of Hygienfresh Essence per kg of garment during the first wash with clean solvent. 1 ml per Kg of garment in next washes without distillation.

Technical Specifications:

- Chemical Composition (REG 648/2004) →>30%:perfumes. 15-30%: non ionic surfactants. <5% limonene, citral, hexyl cinnamal, coumarin, linalool, hydroxycitronellal
- Density at 20°C → 0,980 1,020 g /cm3
- VOC → 21%
- Appearance → Ochre liquid
- Ingredients -> parfum, trideceth-12, ricinus communis oil, ethoxydiglycol, hexamethylindanopyran, diethyl phthalate, citral, hexyl cinnamal, 2,6-dimethyl-7-octen-2ol, limonene, ethyl trimethylcyclopentene butenol, hexyl salicylate, verdyl acetate, 2-t-butylcyclohexyl acetate, anisaldehyde, coumarin, benzyl acetate, linalool.

CODE	PACKAGING	BOX	PALLET
A48-024D	1 Lt	4 pcs	-

All the instructions provided are the result of studies and experiences acquired and they do not exempt the client from verifying the suitability of the products for the purposes of use. Therefore the application of the products and the results obtained must be considered independent from our responsibility

TINTOLAV s.r.l.

Via Massimo d'Antona 7 10028, Trofarello (TO), Italia TEL, +39 011 64 96 827 FAX, +39 011 64 96 742 E-MAIL info@tintolav.com WEB www.tintolav.com •

